


15. 潤滑系統

LUBRICATION MECHANISM



15. 潤滑系統

LUBRICATION MECHANISM

專用機型	序號 Ref. No.	物料編號 Parts No.	名稱 Description	單位用量 Amt. Req
	01	2100001501	防塵泡棉	Bushing 1
	02	2100001502	油嘴	Oil exhaust holder 1
	03	8SC44401208D	螺絲	Screw 1
	04	90OR060	油環	Rubber ring 1
	05	2100001505	油嘴	Oil tube joint 1
	06	66790	油管	Oil tube 1
	07	2110001507	油面鏡	Oil sign gauge 1
	08	-----	停用	-----
	09	-----	停用	-----
	10	-----	停用	-----
	11	-----	停用	-----
	12	2100001512	泵座	Oil pump base 1
	13	8SC44401208D	螺絲	Screw 4
	14	21000001514	齒輪	Gear 2
	15	90OR120	油環	Rubber ring 4
	16	2100001516	蓋板	Cover 1
	17	8SC36400707D	螺絲	Screw 4
	18	2100001518	吸油管	Oil tube 1
	19	2100001519	外蓋	Filter cover 1
	20	2100001520	油封	Filter seat 1
	21	2100001521	紙質過濾器	Cartridge filter 1
	22	2100001522	軸	Shaft 1
	23	2100001523	油嘴	Oil tube joint 1
	24	2100001524	蝸母	Worm gear 1
	25	8SG56320500A	螺絲	Screw 2
	26	2100001526	蝸桿	Worm 1
	27	8SN56320500E	螺絲	Screw 2
	28	2100001528	軸	Shaft 1
	29	8SB44400807A	螺絲	Screw 1
	30	2100001530	分油座	Distribute block 1
	31	2100001531	孔塞	Plug 1
	32	8SB48282009B	螺絲	Screw 2
	33	2100001533	螺絲	Screw 3
	34	2100001534	墊圈	Washer 7
	35	2100001535	油嘴	Oil tube joint 3
	36	2100001536	油管扣環	Snap ring 2
	37	2100001537	油管	Oil tube 1
	38	2100001538	油網	Oil grid 1
	39	2100001539	油嘴	Oil tube joint 1
	40	2100001540	螺絲	Screw 1
	41	2100001541	油管	Oil tube 1
	42	2100001542	防漏墊圈	Washer 1
	43	2100001543	孔塞	Plug 1
	44	2120001220	回路螺絲	Stud 2
01	45	2110001545	油管	Oil tube 1
01	46	2110001546	油封	Oil seal 1
01	47	2110001547	濾心座	Filter seat 1
01	48	8SE44401407A	螺絲	Screw 4
01	49	2100001534	墊圈	Washer 1
01	50	2110001550	分油座	Distribute block 1
01	51	2110001551	油管	Oil tube 1
01	52	2110001552	油環	O-ring 1
01	53	2110001553	油管	Oil tube 1
01	54	2110001554	外蓋	Filter cover 1
01	55	2110001555	螺絲	Screw 1
01	56	8SC44400807D	螺絲	Screw 4
01	57	2100001533	螺絲	Screw 1

01 For OEM 大陸專用機